良值 IINE




复古MINI手柄

IINE Mini Retro Ananke Controller

产品图片仅供参考

Pictures shown for reference only

按键分配



参数：

尺寸:70*41*12(mm)	标配： 手柄*1 说明书*1 1m数据线*1 硅胶挂绳*1
重量:32g	
材质:ABS+铜	休眠电流:<150uA@3.7V
工作电压:3.7V-4.2V	工作电流:<100mA@3.7V

使用前准备

感谢您使用我公司产品。
使用产品前，请仔细阅读以下信息。

支持平台

Switch　手机　平板　PC

注：ios系统仅限原生游戏使用

检查步骤

1.确认产品完整性
在开始使用产品之前，我们需要检查产品是否完整。打开包装盒，仔细检查产品的外观和附件是否齐全，如果发现有损坏或缺失，请立即联系售后服务部门进行处理。

2.外观检查
检查产品的表面是否光滑，没有明显的损伤或裂痕。

3.硬件检查
按钮是否灵敏，摇杆是否活动顺畅，按机械是否正常。

4.阅读产品说明书
在使用产品之前，我们需要仔细阅读产品的说明书，说明书通常包括产品的基本信息、使用方法、注意事项等。确保您了解产品的正确使用方法，我们可以更好地了解产品的特点和功能，并且可以避免一些不必要的错误操作。

5.检查电源和电源线
检查所有的电池是正常，没有电池泄漏或损坏的迹象。同时，检查电池的供电是否充足，以及连接电源的电缆是否有损坏。检查电池和电缆是否有问题。

6.确保使用环境安全
确保您的使用环境是安全的，没有潜在的危险物体或可能的安全问题。例如，检查是否存在易燃易爆物品或者是否有可能使用。使用环境，以免发生意外事故或对产品造成损坏。

7.安装要求
请按照我们的说明书的要求进行安装，这不仅保证了安装的可靠性，还可以避免因为安装不当而导致的问题。

如何连接

首次连接Switch

● 打开Switch配对页面，进入配对模式。



● 长按手柄底部[配对键]至底部LED灯闪烁，完成配对LED蓝灯常亮。



再次连接Switch

●按[HOME]2-3秒至LED亮起，配对成功后LED灯常亮。
LED灯闪烁，自动连接与之配对的主机。
若2分钟回连不成功则自动休眠。



手柄自动休眠

● 主机屏幕关闭，手柄自动休眠。
● 5分钟内无任何操作，手柄自动休眠。
● 蓝牙模式下按[HOME]3秒,选择主机的休眠，进入休眠。




手柄唤醒

● 按[HOME]键2秒唤醒主机。
SWITCH 主机在休眠状态下(非“1行模式下)。



连接PC

1.长按[B+配对键]键至底部LED 1-2灯闪烁，进入配对模式。






2.打开电脑系统设置，选择蓝牙和其他设备并连接。

3.选择Xbox Wireless Controller手柄，完成配对LED1-2常亮。

键盘模式

● 按[Alt+[配对键]至LED1-4灯快闪，连接上后LED1-4常亮。



(关机状态下)

连接手机/平板

安卓

打开手机设置，选择蓝牙。





长按[X+配对键]
至底部LED-3灯闪烁，进入配对模式。
（支持切换，国内世界，日野飙车等）

IOS

打开手机设置，选择蓝牙。





长按[B+配对键]
至底部LED-2闪烁，进入配对模式。
（支持切换，国内世界，日野飙车等ios系统原生游戏）

Anki 软件连接方法：





（MINI手柄配合Anki复习，轻松标记，学习效率翻倍！）

手柄功能设置

连发/自动连发设置

连发：连发模式下，模式灯LED4灯跟随连击频率闪烁：
1.第一次按住[连发键]不放+任意一个动作键，设置手动连发。
2.再次重复第一步的操作，即可自动连发。
3.第三次重复操作，取消按键连发。



（设置连发键，手柄实现自动连击）

摇杆/十字键互换

● 同时按[连发键]和[减号键]互换摇杆和十字键。



（摇杆十字键功能互换）

充电指示

低电量	关机状态下充电	开机状态下充电
		
LED 灯快闪	LED灯闪烁 10s后熄灭	LED灯快闪两次后 恢复到默认灯光

日常维护

- **关于充电：**
  请不要使用大功率或PD快充充电器给手柄充电;充电器充电协议的不一样，可能会导致手柄电路损坏;建议使用5V 1A充电器给手柄充电。
- **防止摔损：**
  游戏手柄内部受到粒尘干扰后，容易产生漂移的可能，建议使用收纳包或其他防护措施，以减少灰尘对产品内部的影响。
- **软件和固件更新：**
  定期检查产品的软件和固件更新，及时安装以获取最新的功能及产品优化。
- **保持通风：**
  建议放在干燥的环境进行保存，确保产品内部的电子元器件不被潮湿的环境破坏掉。
- **防护措施：**
  对于易受损部分，如摇杆和机身，建议使用保护套或保护膜，以减少日常使用中的划痕和碰撞。
- **避免过度使用：**
  避免产品的过度使用，超长时间使用产品可能导致电池寿命减短，在不需要使用时，将设备关闭。
- **电源和电线检查：**
  定期检查电源线和插头的完好性，并且给手柄充电。电池长期处于亏电状态会导致电池损坏。
- **定期检查安全性能：**
  定期检查产品的机械功能，确保装置等硬件正常运作。

手柄故障排除


- **游戏手柄能使用多长时间？**
  您好，我们手柄在正常状态下，可以连续16个小时左右，具体看您使用手柄的情况。
- **如何给产品充电？**
  1.充电线充电:用附送的充电线插到手柄充电口上,即可给手柄充电。

售后服务

服务电话:0769-83189729
服务时间:工作日9:30-18:00
(请准备好购买订单号及产品)

售后及升级请搜索微信公众号：
良值IINE

良值
IINE



IINE Mini Retro
Ananke Controller

Pictures shown for reference only

Product Layout

Features&Specification

Size: 78*41*12(mm)

Weight: 32g

Material: ABS+Copper

Working Voltage: 3.7V-4.2V

List:
Controller*1; 1m Charging Cable*1;
User Manual*1;Silicone Wrist Lanyard*1

Quiescent Current: ≤150uA@3.7V

Working Current: ≤100mA@3.7V

Preparation Steps

Before using the controller, it is important to follow these preparation steps to ensure optimal performance and functionality.

Compatibility



Note: Can only support native gamepad games on iOS APP Store

Check steps

1.Package Checking
Before beginning the controller setup, carefully inspect the package to ensure that all the necessary components are present. If anything is missing or damaged, please contact the manufacturer or retailer for assistance.

2.Controller Inspection
Before proceeding with the setup, carefully inspect the controller and its accessories for any visible damage that may have occurred during shipping or handling.

3.Testing
Before regular use, perform a quick functionality test to ensure all buttons, joysticks, and features are responsive and working correctly.

4.Reading the Product Manual
To maximize your experience with the controller and ensure its proper use, it is highly recommended to thoroughly read the provided product manual before proceeding with setup and operation.

5.Power Supply and Charging Cable Checking
Before use, ensure the charging cable is free from damage, fraying, or exposed wires to guarantee optimal performance and prevent potential issues with the power supply.

6.Environment
Create a secure operating environment for the controller by selecting a well-ventilated and dry area, avoiding exposure to extreme temperatures or moisture, and keeping the controller away from liquids and flammable materials

7.Installation
If the controller requires installation, follow the provided instructions in the user manual for proper setup. Ensure compatibility with your device.

Connection

Switch First Connection

- Open the Switch pairing page to pair the Switch with the controller.



- Press and hold the [Connection] button at the bottom of the controller until the bottom LED light starts flashing, indicating it has entered pairing mode, Once the pairing is successful, the LED will stay blue on.



Reconnect to Switch

- Press the [HOME] button for 2-3 seconds until the LED lights up; **when the controller vibrates, it indicates successful pairing.**
When the LED starts flashing, it means it will automatically connect to the previously connected console. If connection is unsuccessful after 2 min, it will enter disconnect mode automatically.



Sleeping Automatically

- The controller will sleep together with the console if the console sleeps
- Without any operation within 5 minutes, the controller will sleep automatically
- In Bluetooth mode, press the [HOME] button for 3s, select the console's sleep mode, and the controller will enter sleep mode.



Wake up Switch

- Press [HOME] button for 2 seconds to wake up the Switch console
The Switch console is in sleep mode(Not in Airplane mode)



PC Connection

1.Long press [B]+[Connection] buttons until the bottom LED1-2 will flash, indicating that the controller has entered pairing mode.





2. Open the computer system settings,choose [Bluetooth and other devices], and connect the controller.

3.Select [Xbox Wireless Controller]. When the computer completes pairing with the controller, the controller's LED1-2 will flash.

Keyboard Mode

- Press and hold [Alt + [connection] button until the LED1-4 lights start flashing rapidly. Once connected, the LED1-4 lights will stay on.



(In the powered-off state)

Phone/Pad Connection

Android



Open your phone settings and select [Bluetooth].



Long press [X]+[Connection] buttons until the bottom LED2-3 will flash, indicating that the controller has entered pairing mode.
(Supports games like Don't Starve, Minecraft, Asphalt, etc.)

IOS



Open your phone settings and select [Bluetooth].



Long press [B]+[Connection] buttons until the bottom LED1-2 will flash, indicating that the controller has entered pairing mode.
(Supports native IOS games like Don't Starve,Minecraft, Asphalt, etc.)

Connection method for Anki APP



Select the settings icon in the upper right corner.

Click on "Review."

Choose "Game Controller."

Customize button functions in the Game Controller interface.



(Using the IINE Mini Retro Ananke Controller with Anki for review, effortlessly marking, and doubling the efficiency of learning.)

Function Setting

Turbo Function Senting

Turbo: In turbo mode, the mode indicator LED4 flashes in sync with the turbo frequency.

1.Press and hold [Turbo] button + any action button to set Manual Fire

2.Repeat the first step again to set Auto Fire

3.Repeat the operation for the third time to cancel the Turbo



(Setting up Turbo button allows the controller to achieve automatic combos.)

Swapping Button functions

- Simultaneously press the [Turbo] button and the [-] button to swap the Joystick and D-pad functions.



(Swap the functions of the Joystick and D-pad.)

Charging Instructions

Low battery



The LED light flashes quickly.

Charging



The LED light will flash for 10 seconds, then turn off.

Charging complete



The LED light flashes quickly twice, then returns to the default lighting mode.

Routine Maintenance

- **About Charging:**
Recommend to use the 5V 1A charger to prevent damage to the controller circuit, and avoid high-power or PD fast charging chargers due to different charging protocols.
- **Dust Prevention:**
To prevent joystick drifting caused by dust, use a storage bag or other protective measures to minimize dust impact on the inside of the game controller.
- **Firmware Update:**
Check for the latest firmware updates on the manufacturer's website. If updates are available, follow the instructions provided to update the controller's firmware.
- **Ventilation Recommendation:**
Store the controller in a dry environment to safeguard electronic components from potential damage due to humidity.
- **Protective Measures:**
To safeguard vulnerable parts like joystick and joypad, use protective cases or films to minimize scratches and collisions during daily use.
- **Avoid Overuse:**
Prevent overuse to extend battery life. Turn off the equipment when not in use.
- **Power Supply and Cable Inspection:**
Regularly inspect the power cord and plug for integrity. Charge the controller periodically, as prolonged battery depletion can lead to battery damage.
- **Safety Performance Check:**
Regularly examine the mechanical function of the product to ensure the proper operation of the device and other hardware.

Controller Troubleshooting Guide

- **How long can the controller be used?**
Hello! When fully charged, our controller provides up to 16 hours of continuous use, depending on how it' s used.

- **How to Charge the Controller?**
1.Charging with Charging Cable: Plug the provided charging cable into the controller's type-C port to charge it.

After-sale Service

Follow us on Social Media :

Instagram: iline.playmway
Facebook: iline.playmway
Youtube: IINE-Playmway

(If you have any question, please feel free to contact our customer service on the social media or online store.)

良值
IINE




复古MINI手柄

IINE Mini Retro Ananke Controller

产品图片仅供参考
Picture shown is for reference only

按键分配



参数：

尺寸:70*41*12(mm)	标配： 手柄*1 说明书*1 1m数据线*1 硅胶挂绳*1
重量:32g	
材质:ABS+铜	休眠电流:<150uA@3.7V
工作电压:3.7V-4.2V	工作电流:<100mA@3.7V

使用前准备

感谢您使用我公司产品。
使用产品前，请仔细阅读以下信息。

支持平台

Switch　手机　平板　PC

注：ios系统仅限原生游戏使用

检查步骤

1.确认产品完整性
首次检查产品之前，我们重新检查产品是否完整，打开包装箱，仔细检查产品的外观和附件是否齐全，如果发现有损坏或缺少，请立即联系售后服务部门进行处理。

2.外观检查
检查产品的表面是否光滑，没有明显的损伤或裂痕。

3.操作检查
按照说明书上的步骤依次进行操作，确保各项功能正常。

4.阅读产品说明书
在使用产品之前，我们建议您详细阅读产品的说明书，说明书通常包括产品的基本信息、使用方法、注意事项等。请务必按照说明书的指示进行操作，以确保正确和安全地使用产品。

5.检查电源和电源线
检查所使用的充电设备是否正常，是否有损坏的情况。确保电源线连接稳定，没有松动或损坏的情况。

6.确保使用环境安全
检查产品的使用环境，确保没有潜在的安全隐患。例如，检查是否有易燃物品或危险物质在附近，确保使用环境安全。

7.保留票据
请您保留好您的购买凭证和票据，以便在需要行使保修权益或进行退换货时使用。

如何连接

首次连接Switch

● 打开Switch配对页面，进入配对模式。



● 长按手柄底部[配对键]至底部LED灯闪烁，完成配对LED显灯常亮。



再次连接Switch

● 按[HOME]2-3秒至LED亮起,配对成功后LED灯常亮。
LED灯闪烁,自动连接与之配对的主机。
若2分钟回连不成功则自动关机。



手柄自动休眠

● 主机屏幕关闭,手柄自动休眠。
● 5分钟内无任何操作,手柄自动休眠。
● 蓝牙模式下按[HOME]3秒,选择主机的休眠,进入休眠。



手柄唤醒

● 按[HOME]键2秒唤醒主机。
SWITCH 主机在休眠状态下(非飞行模式下)。




连接PC

1.长按[B+配对键]键至底部LED 1-2灯闪烁,进入配对模式。



2.打开电脑系统设置,选择蓝牙和其他设备并连接。



3.选择Xbox Wireless Controller手柄,完成配对LED1-2常亮。

键盘模式

● 按[A]+[配对键]至LED1-4灯快闪,连接上后LED1-4常亮。



(关机状态下)

连接手机/平板

安卓

打开手机设置,选择蓝牙。



长按[X+配对键]
至底部LED1-2灯闪烁,进入配对模式。
(支持饥荒、我的世界、狂野飙车等)

IOS

打开手机设置,选择蓝牙。



长按[B+配对键]
至底部LED1-2灯闪,进入配对模式。
(支持饥荒、我的世界、狂野飙车等)
(ios系统原生游戏)

Anki 软件连接方法:



(MINI手柄配合Anki复习，轻松标记，学习效率翻倍!)

手柄功能设置

连发/自动连发设置

连发：连发模式下，模式灯LED4灯跟随连击频率闪烁：
1.第一次按住[连发键]不放+任意一个动作键,设置手动连发。
2.再次重复第一步的操作,即可自动连发。
3.第三次重复操作,取消按键连发。



(设置连发键，手柄实现自动连击)

摇杆/十字键互换

● 同时按[连发键]和[减号键]互换摇杆和十字键。



(摇杆十字键功能互换)

充电指示

低电量	关机状态下充电	开机状态下充电
LED 灯快闪	LED灯闪烁 10s后熄灭	LED灯保持为两次后 恢复到默认灯光

日常维护

● **关于充电：**
请不要使用大功率或PD快充充电器给手柄充电;充电器充电协议的不一样，可能会导致手柄电路损坏;建议使用5V 1A充电器给手柄充电。

● **防尘措施：**
游戏手柄内部受到粉尘干扰后，容易产生漂移的可能，建议使用收纳包或其他防护措施，以减少灰尘对产品内部的影响。

● **软件和固件更新：**
定期检查产品的软件和固件更新，及时安装以获取最新的功能及产品优化。

● **保持通风：**
建议放在干燥的环境进行保存，确保产品内部的电子元器件不被潮湿的环境破坏掉。

● **防护措施：**
对于易受损部位，如摇杆和机身，建议使用保护套或保护膜，以减少日常使用中的划痕和碰撞。

● **避免过度使用：**
避免产品的过度使用,超长时间使用产品可能导致电池寿命减短,在不需要使用时,将设备关闭。

● **电源和电线检查：**
定期检查电源线和插头的完好性，并且给手柄充电。电池长期处于亏电状态会导致电池损坏。

● **定期检查安全性能：**
定期检查产品的机械功能,确保装置等硬件正常运作。

手柄故障排除

● **游戏手柄能使用多长时间?**
您好，我们手柄在正常状态下，可以连续16个小时左右，具体看您使用手柄的情况。

● **如何给产品充电?**
1.为电线充电:用附送的充电线插到手柄充电口上,即可给手柄充电。

售后服务

服务电话:0769-83189729
服务时间:工作日9:30-18:00
(请准备好购买订单号及产品)


售后及升级请搜索微信公众号：
良值IINE

IINE



IINE Mini Retro Ananke Controller

Product Layout



Features&Specification

Size: 78*42*12(mm)	**List:** Controller*1; 1m Charging Cable*1; User Manual*1;Silicone Wrist Lanyard*1
Weight: 51g	
Material: ABS+Copper	**Quiescent Current:**≤150uA@3.7V
Working Voltage: 3.7V-4.2V	**Working Current:**≤100mA@3.7V

Preparation Steps

Before using the controller, it is important to follow these preparation steps to ensure optimal performance and functionality.

Compatibility



Note: Can only support native gamepad games on iOS APP Store

Check steps

1.Package Checking
Before starting the controller setup, carefully inspect the package to ensure that all the necessary components are present. If anything is missing or damaged, please contact the manufacturer or retailer for assistance.

2.Controller Inspection
Before proceeding with the setup, carefully inspect the controller and its accessories for any visible damage that may have occurred during shipping or handling.

3.Testing
Before regular use, perform a quick functionality test to ensure all buttons, joysticks, and features are responsive and working correctly.

4.Reading the Product Manual
Before attempting to set up and operate the controller and ensure its proper use, it is highly recommended to thoroughly read the provided product manual before proceeding with setup and operation.

5.Power Supply and Charging Cable Checking
Before use, ensure the charging cable is free from damage, fraying, or exposed wires to guarantee optimal performance and prevent potential issues with the power supply.

6.Environment
Create a secure operating environment for the controller by selecting a well-ventilated and dry area, avoiding exposure to extreme temperatures or moisture, and keeping the controller away from liquids and flammable materials

7.Installation
If the controller requires installation, follow the provided instructions in the user manual for proper setup. Ensure compatibility with your device.

Connection

Switch First Connection

- Open the Switch pairing page to pair the Switch with the controller.



- Press and hold the [Connection] button at the bottom of the controller until the bottom LED light starts flashing, indicating it has entered pairing mode, Once the pairing is successful, the LED will stay blue on.



Reconnect to Switch

- Press the [HOME] button for 2-3 seconds until the LED lights up; when the controller vibrates, it indicates successful pairing.
  When the LED starts flashing, it means it will automatically connect to the previously paired console. If reconnection is unsuccessful after 2 min, it will enter sleep mode automatically.



Sleeping Automatically

- The controller will sleep together with the console if the console sleeps
- Without any operation within 5 minutes, the controller will sleep automatically
- In Bluetooth mode, press the [HOME] button for 3s, select the console's sleep mode, and the controller will enter sleep mode.



Wake up Switch

- Press [HOME] button for 2 seconds to wake up the Switch console
  The Switch console is in sleep mode(Not in Airplane mode)



PC Connection

1.Long press [B]+[Connection] buttons until the bottom LED1-2 will flash, indicating that the controller has entered pairing mode.



2. Open the computer system settings,choose [Bluetooth and other devices], and connect the controller.



3.Select [Xbox Wireless Controller]. When the computer completes pairing with the controller, the controller's LED1-2 will flash.

Keyboard Mode

- Press and hold [A] + [Connection] button until the LED1-4 lights start flashing rapidly. Once connected, the LED1-4 lights will stay on.



(In the powered-off state)

Phone/Pad Connection

Android



Open your phone settings and select [Bluetooth].




Long press [X]+[Connection] buttons until the bottom LED2-3 will flash, indicating that the controller has entered pairing mode.

(Supports games like Don't Starve, Minecraft, Asphalt, etc.)

IOS



Open your phone settings and select [Bluetooth].



Long press [B]+[Connection] buttons until the bottom LED1-2 will flash, indicating that the controller has entered pairing mode.

(Supports native IOS games like Don't Starve,Minecraft, Asphalt, etc.)

Connection method for Anki APP





(Using the IINE Mini Retro Anankе Controller with Anki for review, effortlessly marking, and doubling the efficiency of learning.)

Function Setting

Turbo Function Senting

Turbo: In turbo mode, the mode indicator LED4 flashes in sync with the turbo frequency.

1.Press and hold [Turbo] button + any action button to set Manual Fire

2.Repeat the first step again to set Auto Fire

3.Repeat the operation for the third time to cancel the Turbo



(Setting up Turbo button allows the controller to achieve automatic combos.)

Swapping Button functions

- Simultaneously press the [Turbo] button and the [-] button to swap the Joystick and D-pad functions.



(Swap the functions of the Joystick and D-pad.)

Charging Instructions

Low battery	Charging	Charging complete
		
The LED light flashes quickly.	The LED light will flash for 10 seconds, then turn off.	The LED light flashes quickly twice, then returns to the default lighting mode.

Routine Maintenance

- **About Charging:**
  Recommend to use the 5V 1A charger to prevent damage to the controller circuit, and avoid high-power or PD fast charging chargers due to different charging protocols.
- **Dust Prevention:**
  To prevent joystick drifting caused by dust, use a storage bag or other protective measures to minimize dust impact on the inside of the game controller.
- **Firmware Update:**
  Check for the latest firmware updates on the manufacturer's website. If updates are available, follow the instructions provided to update the controller's firmware.
- **Ventilation Recommendation:**
  Store the controller in a dry environment to safeguard electronic components from potential damage due to humidity.
- **Protective Measures:**
  To safeguard vulnerable parts like joystick and joypad, use protective cases or films to minimize scratches and collisions during daily use.
- **Avoid Overuse:**
  Prevent overuse to extend battery life. Turn off the equipment when not in use.
- **Power Supply and Cable Inspection:**
  Regularly inspect the power cord and plug for integrity. Charge the controller periodically, as prolonged battery depletion can lead to battery damage.
- **Safety Performance Check:**
  Regularly examine the mechanical function of the product to ensure the proper operation of the device and other hardware.

Controller Troubleshooting Guide

- **How long can the controller be used?**
  Hello! When fully charged, our controller provides up to 16 hours of continuous use, depending on how it`s used.

- **How to Charge the Controller?**
  1.Charging with Charging Cable: Plug the provided charging cable into the controller's type-C port to charge it.

After-sale Service

Follow us on Social Media :

Instagram: iine.playmway
Facebook: iine.playmway
Youtube: IINE:Playmway

(If you have any question, please feel free to contact our customer service on the social media or online store.)

良值
IINE




复古MINI手柄

IINE Mini Retro Ananke Controller

产品图片仅供参考
Pictures shown for reference only

CE

按键分配



参数：

尺寸:70*41*12(mm)	标配： 手柄*1 说明书*1 1m数据线*1 硅胶挂绳*1
重量:32g	
材质:ABS+铜	休眠电流:<150uA@3.7V
工作电压:3.7V-4.2V	工作电流:<100mA@3.7V

使用前准备

感谢您使用我公司产品。
使用产品前，请仔细阅读以下信息。

支持平台

Switch　手机　平板　PC

注:ios系统仅限原生游戏使用

检查步骤

1.确认产品完整性
在开始使用产品之前，我们建议您检查产品是否完整。打开包装后，仔细检查产品的外观和附件是否齐全，如果发现任何损坏或缺失，请及时联系售后服务部门进行处理。

2.外观检查
检查产品的外观是否良好，没有明显的损伤或缺陷。

3.操作检查
初始状态下，按下按键后将会出现响应，反应速度也良好。

4.测试产品说明书
在使用产品之前，我们建议您详细阅读产品的说明书，说明书通常包括产品的基本信息、使用方法、注意事项等。请确保您了解并遵守说明书中的所有指示和警告，以避免出现不必要的问题或损坏。

5.检查电源和电源线
检查您所使用的充电电源是否正常，是否能够为手柄提供所需的电压和电流。同时，检查连接手柄和电源的电源线是否完好无损，确保没有断裂或短路等问题。

6.确保使用环境安全
在使用产品时，请确保周围环境没有可燃物质或危险物品，以免发生意外事故。同时，也要注意避免将产品暴露在潮湿、高温或低温等恶劣环境中，以免影响产品的性能和寿命。

7.保修要求
请您保留好您的包装盒以及配发清单，以便在需要时享受我们提供的保修服务。

如何连接

首次连接Switch

● 打开Switch配对页面，进入配对模式。



● 长按手柄底部[配对键]至底部LED灯闪烁，完成配对LED蓝灯常亮。



再次连接Switch

●按[HOME]2-3秒至LED亮起,配对成功后LED灯常亮。
LED灯闪烁,自动连接与之配对的主机。
若2分钟回连不成功则自动休眠。



手柄自动休眠

● 主机屏幕关闭,手柄自动休眠。
● 5分钟内无任何操作,手柄自动休眠。
● 蓝牙模式下按[HOME]3秒,选择主机的休眠,进入休眠。



手柄唤醒

● 按[HOME]键2秒唤醒主机。
SWITCH 主机在休眠状态下(非飞行模式下)。



连接PC

1.长按[B+配对键]键至底部LED 1-2灯闪烁,进入配对模式。



2.打开电脑系统设置,选择蓝牙和其他设备并连接。



3.选择Xbox Wireless Controller手柄,完成配对LED1-2常亮。

键盘模式

● 按[A]+[配对键]至LED1-4灯快闪,连接上后LED1-4常亮。



(关机状态下)

连接手机/平板

安卓

打开手机设置,选择蓝牙。



长按[X+配对键]
至底部LED1-2灯闪烁,进入配对模式。
(支持饥荒,我的世界,狂野飙车等)

IOS

打开手机设置,选择蓝牙。



长按[B+配对键]
至底部LED1-2灯闪烁,进入配对模式。
(支持饥荒,我的世界,狂野飙车等ios系统原生游戏)

Anki 软件连接方法:



(MINI手柄配合Anki复习,轻松标记,学习效率翻倍!)

手柄功能设置

连发/自动连发设置

连发:连发模式下,模式灯LED4灯圈随连击频率闪烁:
1.第一次按住[连发键]不放+任意一个动作键,设置手动连发。
2.再次重复第一步的操作,即可自动连发。
3.第三次重复操作,取消按键连发。



(设置连发键,手柄实现自动连击)

摇杆/十字键互换

● 同时按[连发键]和[减号键]互换摇杆和十字键。



(摇杆十字键功能互换)

充电指示

低电量	关机状态下充电	开机状态下充电
LED灯快闪	LED灯2档 10s熄灭	LED灯档位两次后 恢复到默认灯光

日常维护

- **关于充电:**
请不要使用大功率或PD快充充电器给手柄充电;充电器充电协议的不一样,可能会导致手柄电路损坏;建议使用5V 1A充电器给手柄充电。
- **防尘措施:**
游戏手柄内部受到粉尘干扰后,容易产生漂移的可能,建议使用收纳包或其他防护措施,以减少灰尘对产品内部的影响。
- **软件和固件更新:**
定期检查产品的软件和固件更新,及时安装以获取最新的功能及产品优化。
- **保持通风:**
建议放在干燥的环境进行保存,确保产品内部的电子元器件不被潮湿的环境破坏掉。
- **防护措施:**
对于易受损部位,如摇杆和机身,建议使用保护套或保护膜,以减少日常使用中的划痕和碰撞。
- **避免过度使用:**
避免产品的过度使用,超长时间使用产品可能导致电池寿命减短,在不需要使用时,将设备关闭。
- **电源和电线检查:**
定期检查电源线和插头的完好性,并且检手柄充电,电池长期处于亏电状态会导致电池损坏。
- **定期检查安全性能:**
定期检查产品的机械功能,确保装置等硬件正常运作。

手柄故障排除

- **游戏手柄能使用多长时间?**
您好,我们手柄在正常状态下,可以连续16个小时左右,具体看您使用手柄的情况。
- **如何给产品充电?**
1.为电线充电:用附送的充电线链到手柄充电口上,即可给手柄充电。

售后服务

服务电话:0769-83189729
服务时间:工作日9:30-18:00
(请准备好购买订单号及产品)


售后及升级请搜索微信公众号:
良值IINE

良值
IINE



IINE Mini Retro Ananke Controller

Product Layout



Features&Specification

Size: 79*42*12(mm)

Weight: 53g

Material: ABS+Copper

Working Voltage: 3.7V-4.2V

List:
Controller*1; 1m Charging Cable*1;
User Manual*1;Silicone Wrist Lanyard*1

Quiescent Current: ≤150uA@3.7V

Working Current: ≤100mA@3.7V

Actuals shown for reference only

Preparation Steps

Before using the controller, it is important to follow these preparation steps to ensure optimal performance and functionality.

Compatibility



Note: Can only support native gamepad games on iOS APP Store

Check steps

1.Package Checking
Before starting the controller setup, carefully inspect the package to ensure that all the necessary components are present. If anything is missing or damaged, please contact the manufacturer or retailer for assistance.

2.Controller Inspection
Before proceeding with the setup, carefully inspect the controller and its accessories for any visible damage that may have occurred during shipping or handling.

3.Testing
Before regular use, perform a quick functionality test to ensure all buttons, joysticks, and features are responsive and working correctly.

4.Reading the Product Manual
To familiarize yourself with the specific controller and ensure its proper use, it is highly recommended to thoroughly read the provided product manual before proceeding with setup and operation.

5.Power Supply and Charging Cable Checking
Before use, ensure the charging cable is free from damage, fraying, or exposed wires to guarantee optimal performance and prevent potential issues with the power supply.

6.Environment
Create a secure operating environment for the controller by selecting a well-ventilated and dry area, avoiding exposure to extreme temperatures or moisture, and keeping the controller away from liquids and flammable materials

7.Installation
If the controller requires installation, follow the provided instructions in the user manual for proper setup. Ensure compatibility with your device.

Connection

Switch First Connection

- Open the Switch pairing page to pair the Switch with the controller.



- Press and hold the [Connection] button at the bottom of the controller until the bottom LED light starts flashing, indicating it has entered pairing mode, Once the pairing is successful, the LED will stay blue on.



Reconnect to Switch

- Press the [HOME] button for 2-3 seconds until the LED lights up; when the controller vibrates, it indicates successful pairing.
When the LED starts flashing, it means it will automatically connect to the previously paired console. If reconnection is unsuccessful after 2 min, it will enter sleep mode automatically.



Sleeping Automatically

- The controller will sleep together with the console if the console sleeps
- Without any operation within 5 minutes, the controller will sleep automatically
- In Bluetooth mode, press the [HOME] button for 3s, select the console's sleep mode, and the controller will enter sleep mode.



Wake up Switch

- Press [HOME] button for 2 seconds to wake up the Switch console
The Switch console is in sleep mode(Not in Airplane mode)



PC Connection

1.Long press [B]+[Connection] buttons until the bottom LED1-2 will flash, indicating that the controller has entered pairing mode.

2. Open the computer system settings,choose [Bluetooth and other devices], and connect the controller.

3.Select [Xbox Wireless Controller]. When the computer completes pairing with the controller, the controller's LED1-2 will flash.

Keyboard Mode

- Press and hold [A] + [Connection] button until the LED1-4 lights start flashing rapidly. Once connected, the LED1-4 lights will stay on.

(In the powered-off state)

Phone/Pad Connection

Android



Open your phone settings and select [Bluetooth].



Long press [X]+[Connection] buttons until the bottom LED2-3 will flash, indicating that the controller has entered pairing mode.

(Supports games like Don't Starve, Minecraft, Asphalt, etc.)

IOS



Open your phone settings and select [Bluetooth].



Long press [B]+[Connection] buttons until the bottom LED1-2 will flash, indicating that the controller has entered pairing mode.

(Supports native iOS games like Don't Starve,Minecraft, Asphalt, etc.)

Connection method for Anki APP



Select the settings icon in the upper right corner.



Click on "Review."



Choose "Game Controller."



Customize button functions in the Game Controller interface.



(Using the IINE Mini Retro Ananke Controller with Anki for review, effortlessly marking, and doubling the efficiency of learning.)

Function Setting

Turbo Function Senting

Turbo: In turbo mode, the mode indicator LED4 flashes in sync with the turbo frequency.

1.Press and hold [Turbo] button + any action button to set Manual Fire

2.Repeat the first step again to set Auto Fire

3.Repeat the operation for the third time to cancel the Turbo



(Setting up Turbo button allows the controller to achieve automatic combos.)

Swapping Button functions

- Simultaneously press the [Turbo] button and the [-] button to swap the Joystick and D-pad functions.



(Swap the functions of the Joystick and D-pad.)

Charging Instructions



The LED light flashes quickly.

The LED light will flash for 10 seconds, then turn off.

The LED light flashes quickly twice, then returns to the default lighting mode.

Routine Maintenance

- **About Charging:**
Recommend to use the 5V 1A charger to prevent damage to the controller circuit, and avoid high-power or PD fast charging chargers due to different charging protocols.
- **Dust Prevention:**
To prevent joystick drifting caused by dust, use a storage bag or other protective measures to minimize dust impact on the inside of the game controller.
- **Firmware Update:**
Check for the latest firmware updates on the manufacturer's website. If updates are available, follow the instructions provided to update the controller's firmware.
- **Ventilation Recommendation:**
Store the controller in a dry environment to safeguard electronic components from potential damage due to humidity.
- **Protective Measures:**
To safeguard vulnerable parts like joystick and joypad, use protective cases or films to minimize scratches and collisions during daily use.
- **Avoid Overuse:**
Prevent overuse to extend battery life. Turn off the equipment when not in use.
- **Power Supply and Cable Inspection:**
Regularly inspect the power cord and plug for integrity. Charge the controller periodically, as prolonged battery depletion can lead to battery damage.
- **Safety Performance Check:**
Regularly examine the mechanical function of the product to ensure the proper operation of the device and other hardware.

Controller Troubleshooting Guide

- **How long can the controller be used?**
Hello! When fully charged, our controller provides up to 16 hours of continuous use, depending on how it`s used.
- **How to Charge the Controller?**
1.Charging with Charging Cable: Plug the provided charging cable into the controller's type-C port to charge it.

After-sale Service

Follow us on Social Media :

Instagram: iine.playmway
Facebook: iine.playmway
Youtube: IINE:Playmway

(If you have any question, please feel free to contact our customer service on the social media or online store.)